



## Mobi-Fence™ INSTALLATION DATA SHEET

### Required material

#### Mobi-Fence™ fabric:

Delivered in rolls 164' x 39" (50 x 1 m) with included channels 4" (100 mm) diameter in order to insert stakes of fixation.

Approximate weight of a roll : 44 lb (20 Kg)

#### Wooden stakes : round and smooth if possible:

For channels 4" (100 mm) diam, stakes 3.15" (80 mm) diam and 60" (1.50 m) high

For channels 6" (150 mm) diam, stakes 4.72" (120 mm) diam and 120" (2.00 m) high

#### Material for cutting:

Hot cut or soldering iron in order to avoid raveling  
(please cut at about 4" (100 mm) from the channels)

#### Setting material:

Digger to push in the stakes, sand spade

#### People:

It is better to be 2 people

### Installation

Prepare the Mobi-Fence™ at the expected length (cauterize the fabric with a soldering iron in order to avoid the raveling) ([Picture 1](#)).

**Be careful : Check that the wooden stakes, when digging in, do not ravel the fabric (sliver of wood). If raveled, melt the fabric with a soldering iron.**

Prepare the ground by digging a drainage channel of about 4" x 4" (100 x 100 mm).

Unroll the Mobi-Fence™.

Insert the 1<sup>st</sup> stake in the 1<sup>st</sup> channel ([Picture 2](#)).

Raise the set and dig in the 1<sup>st</sup> stake ([Picture 3](#)).

Insert the 2<sup>nd</sup> stake in the 2<sup>nd</sup> channel ([Picture 4](#)).

Stretch the fabric at the maximum.

Dig in the 2<sup>nd</sup> stake.

After positioning the all length, add some sand at the bottom of the fabric, around 8" (20 cm), in order to avoid the wind rushing under the fabric and making a hole ([Picture 5](#)).



Picture 1



Picture 2



Picture 3



Picture 4



Picture 5

# D M S

DESCHAMPS MAT SYSTEMS

[info@mobi-mat-dms.com](mailto:info@mobi-mat-dms.com)

218 Little Falls Road, Unit 7 - Cedar Grove, NJ 07009 - USA

Tel. + 1 973 928 3040 - Fax. + 1 973 928 3041

[www.mobi-mat-dms.com](http://www.mobi-mat-dms.com)